



# Installationsanvisning / Installation guide

## MultiWeb G4T



**OBS! Koppla bort samtliga kraftkällor från enheten innan fortsatt installation.**

### Varning:

- ✓ Max 230VAC nominell mellan L1 och N.
- ✓ Tillverkaren tar inget ansvar för fel som uppkommer om utrustningen inte handhas enligt specifikation.
- ✓ En switch eller strömbrytare skall alltid inkluderas i installationen.
  - ↪ Denna skall placeras i absolut närhet till enheten och tillgänglig för operatören.
  - ↪ Denna skall märkas som nedkopplande anordning för utrustningen.

4 st S0-ingångar ansluts till valfri mätare med pulsutgång, t.ex. el-, vatten-, värmemängdsmätare

### Alternativ:

PLC-kommunikation för överföring av data överlagrat på elnät.



**Caution! Disconnect all power sources from the unit before pursuing.**

### Warning:

- ✓ Maximum 230VAC between L1 and N.
- ✓ The manufacturer will not be held responsible if the equipment is used in a manner not specified.
- ✓ A switch or circuit-breaker shall be included in the building installation.
  - ↪ It shall be in close proximity to the equipment and within easy reach of the OPERATOR.
  - ↪ It shall be marked as the disconnecting device for the equipment.

4 S0 pulse inputs can be connected to optional meter with pulse output i.e. electricity, water or gas.

### Alternative:

PLC - Power Line Communication.